

IMPORTANT THINGS TO KNOW



OUR PRODUCT RANGE

HOW TO USE NEO SALT STOP



Always follow the instructions on the product label for best results.



Preparation and correct product application are important.



There are no short-cuts. Always follow the correct drying time recommendations.



High moisture and alkaline (salt) content in a wall reacts with paint and will cause paint failure if not properly treated.



Keep the room well ventilated when using an oil-based/solvent based paint.

HANDY PAINTING TIPS



Clean your brushes used for PVA with a pail of soapy water after use. Work the bristles with your hand.



Clean your brushes used for enamel paint, with Mineral Turpentine instead of soapy water. Rinse the brush clean.



Treat not just the patches, but also at least 1 meter around the damp patch.



For an exterior Parapet wall, apply NEO Salt Stop on top of the wall and 50mm over the edges on all sides of the wall.



Use correct safety equipment for your own protection e.g. safety glasses, gloves and protective clothing.



For serious damp problems, please phone our technical helpline for support.
Tel: +264 61 384 724

PRODUCT NAME		NEO SALT STOP
APPLICATION AREAS	INTERIOR	X
	EXTERIOR	X
SURFACES	CONCRETE	X
	PLASTER	X

Technical helpline: Tel: +264 61 384 724



WALL PAINTS

Water and enamel based paints. Use on walls, fibre cement, partitioning, wood and metal



GLOSS PAINTS

Water and enamel based paints give a hard, glossy finish. Use on metal, wood and other surfaces.



PRIMERS AND UNDERCOATS

Specialist products to seal the surface and provide better bonding between the surface and top coat.



REPAIR AND RENOVATION

Wide range of products to prepare the surface for painting.



LAQUERS AND VARNISH

Wide range to varnish and protect wooden surfaces.



SPECIALISED PRODUCTS

Formulated for special applications for e.g. pool paint, roof paint etc.



SOLVENTS & THINNERS

Product range to thin paint and to clean painting tools.

WINDHOEK HEAD OFFICE

12 Bell Street, Southern Industry, Windhoek
T: +264 61 384 700

WALVIS BAY REGIONAL OFFICE

Hanna Mupatani Road, Walvis Bay
T: +264 64 204 026

www.neopaints.com [f/NEOpaintsNamibia](https://www.facebook.com/NEOpaintsNamibia)

PA!NTNAM!B!A

HANDY TIPS ON HOW TO PREVENT AND TREAT MOISTURE PROBLEMS BY USING NEO SALT STOP



NEO Salt Stop is the ultimate blocking agent to stop and prevent the migration of salt, alkaline and moisture in cement surfaces.

A coat of excellence



start

1

Ensure previously painted surfaces are clean by removing any flaking paint with a scraper or stiff nylon brush.

If the plaster is damaged, remove all damaged plaster down to the brick work.

Apply new plaster where necessary. Dilute **NEO Salt Stop** with clean water as per product specifications (1:9). Apply one generous coat of NEO Salt Stop on all bare exposed cement surfaces only and allow to dry for 24 hours.

THINGS YOU WILL NEED

Nylon brush

Hamilton's Viva 100mm brush

3

Fill the cracks with **NEO Repair Paste**.

Larger cracks must be filled in 2mm layers until the crack is filled.

Let each layer dry for 1 hour.

THINGS YOU WILL NEED

Hamilton's Scraper

4

Apply one coat of **NEO Salt Stop** once all the repair work has been completed.

Allow 2 hours to dry.

5

BOUNDARY WALL TREATMENT:

Paint entire wall with one generous coat of **NEO Salt Stop**. Dilute **NEO Salt Stop** with clean water as per product specifications (1:9). Only if not previously painted. If previously painted, only treat bare exposed cement surfaces with Salt Stop.

Seal the top of the wall with **NEO Elastic Waterproofing** by painting two coats on the top, and 50mm over the edges of the wall.

6

Apply 1 coat **NEO Contractors Premium Primer** before applying two coats of NEO PVA of choice.

Best options will be to choose from:

- **NEO Dur Semi-Matt PVA** (SABS Grade 1)
- **NEO Multi Dur Matt PVA** (SABS Grade 2)

Allow adequate drying times between coats.

- Use a paint brush to create 2- to 3-cm bands around the edges, corners and frames of a room.
- Use a paint roller to paint the larger wall.

THINGS YOU WILL NEED

Hamilton's Specialist Waterproofing 120mm Brush

finish

THINGS YOU WILL NEED

Hamilton's Stainless Steel Scraper

MORE HANDY TOOLS



Wire Brush



Scraper



Sand paper



Paint Tray



Paint Roller



Paint Brush